

Car Data Sheet

W639 Mercedes Vito/V Class Van 2003 -

7-Core Entry Point	Longer 7 Core Cable	Bypass Recommended If TF2302, see SmartCAN data	Other Relay Recommended
19/21 Grommet		TF2218/7SMARTLOGIC	
Automatic Trailer Flasher Monitor	Reversing Sensor	Cut Out Switch, etc.	Mfr's Towing Plug
<input type="checkbox"/>			

Find Constant Live Colour: Location: 21 Add Fuse:	Find Ignition-Switched Live Colour: Location: Add Fuse:
---	---

Best Wiring Location	Route to Battery	Fusebox Location
21 lamp		

Choose power source carefully. On cars with power management (ID by battery condition in display) do not go to the battery.

Fitting times, etc. Notes

Wire positions and connection points etc are given. Use probe to identify correct wire in location.
These notes relate fitting bypass relay. For TF2302 SmartCAN, see SmartCAN Data

Lights	Vehicle Wire Colours	Alternative	Location
LH Flasher	Black/white		
Fog Light	Grey/green		
RH Flasher	Black/green		
RH Side Light	Grey/red		
Brake Light	Black/red		
LH Side Light	Grey/black		
Reverse	White/blue		

